



Notes:

- Fixings through top of parapet are not permitted.
- Ensure parapet is temporarily waterproofed prior to plastering.
- Install metal saddle flashing at wall junction.
- Install metal capping to all roof parapets
- Metal cap excluding drip edge must overlap board by 100mm minimum.
- Refer to NZBC E2/AS1 Table 7 for flashing cover dimensions.

© 2019 Petros Holdings Ltd



61 Hillside Rd, Wairau Valley
Auckland 0627
New Zealand
www.mineralplaster.co.nz Ph: 0800 25 23 678

MPT Liteclad System
Parapet - Flat

Reference: mpt_I081

Date: January 2020

Scale: 1 : 2 @ A4

Revision: 2